

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
Audiovox	
DC400	Palm
Canon	
Digital IXUS 30/40/50/55/60/65	Small Point & Shoot
Digital IXUS 330/400/430/500	Small Point & Shoot
Digital IXUS 800 / 850 IS	Small Point & Shoot
Digital IXUS i5/i/i zoom	Small Point & Shoot
Digital IXUS II/IIIs	Small Point & Shoot
Digital IXUS v2/v3	Small Point & Shoot
Digital IXUS Wireless	Small Point & Shoot
Digital IXUS 750	Large Point & Shoot
EOS 3	Sorry, no fit
EOS 1D/1D Mark II N/1Ds/1Ds Mark II	Sorry, no fit
EOS 5/10/20/30D/D60	Sorry, no fit
EOS 20Da	Sorry, no fit
EOS 3000N	SLR
EOS 1V	Sorry, no fit
EOS 33V	Sorry, no fit
EOS 50E/Elan IIE	Sorry, no fit
EOS 30V Date	Sorry, no fit
EOS 300V/3000V	SLR
EOS 300/300X/350D/400D/ Rebel XT	SLR
EOS 300D	SLR
EOS 400D	SLR
Powershot A30/60/70/75/80/85/95	Small Point & Shoot
Powershot A300/310/400/410/420/430	Small Point & Shoot
PowerShot A460	Small Point & Shoot
PowerShot A650	Large Point & Shoot
Powershot A510/520/530/540/550	Small Point & Shoot
PowerShot A560	Small Point & Shoot
PowerShot A570	Small Point & Shoot
Powershot A700	Large Point & Shoot
Powershot A720IS	Large Point & Shoot
Powershot A710IS	Small Point & Shoot
Powershot A610/A620/A630	Large Point & Shoot
Powershot G1/2/3/6	Large Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
Powershot G5	SLR or Large Point & Shoot
Powershot G7	Small Point & Shoot
PowerShot G9	Small Point & Shoot
Powershot Pro 1	Sorry, no fit
Powershot S1 IS	SLR or Large Point & Shoot
Powershot S2 IS	Sorry, No fit
Powershot S5 IS	SLR or Large Point & Shoot
Powershot S3 IS	SLR or Large Point & Shoot
Powershot S45/50/60/70/80/410	Small Point & Shoot
Powershot SD300/400/430/450/600	Small Point & Shoot
PowerShot A720 IS	Small Point & Shoot
PowerShot SD700 / 750	Mini Point & Shoot or Small Hard Lens
PowerShot SD870	Mini Point & Shoot or Small Hard Lens
Powershot SD900	Small Point & Shoot
PowerShot SD1000	Mini Point & Shoot or Small Hard Lens
Powershot SD800 IS / 850IS	Mini Point & Shoot or Small Hard Lens
PowerShot SD950	Mini Point & Shoot or Small Hard Lens
PowerShot SX100	Large Point & Shoot
Prima Super 90u/115u/130u/150u/180 Date	Small Point & Shoot
Casio	
Exilim Card EX - S100/600	Small Point & Shoot
Exilim Pro EX - P600/700	Small Point & Shoot
Exilim Pro EX - P505	Large Point & Shoot
Exilim Zoom EX - 750	Small Point & Shoot
Exilim Zoom EX - S500	Small Point & Shoot
Exilim EX-S880	Mini Point & Shoot or Small Hard Lens
Exilim Zoom EX - Z30	Large Point & Shoot
Exilim Zoom EX - Z110/120	Small Point & Shoot
Exilim Zoom EX - Z40/55/57/60/70	Small Point & Shoot
Exilim EX-Z77 New	Sorry, no fit
Exilim Zoom EX - Z500/600/750/850/1000	Small Point & Shoot
Exilim EX-Z1080	Mini Point & Shoot or Small Hard Lens
Exilim EX-Z1200	Small Point & Shoot
Exilim EX-V8	Mini Point & Shoot or Small Hard Lens
QV R41/51/61	Small Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
Contax	
Aria	SLR
G1/2 Rangefinder	Large Point & Shoot
N1 Auto Focus	Sorry, no fit
NX Auto Focus	Sorry, no fit
RTS III	Sorry, no fit
RX II	Sorry, no fit
T Series T3	Small Point & Shoot
T Series Tix	Small Point & Shoot
T Series TVS III (No JPG image available)	Sorry, no fit
U4R/I4R	Small Point & Shoot
Epson	
P-2000/4000	Small Point & Shoot
RD1	Small Point & Shoot
Fuji	
@xia SlimShot	Small Point & Shoot
FinePix A120	Small Point & Shoot
FinePix A330/340/345/350/360 Zoom	Small Point & Shoot
FinePix A370	Small Point & Shoot
FinePix A400/405/410 Zoom	Small Point & Shoot
FinePix A403	Small Point & Shoot
FinePix A500 Zoom	Small Point & Shoot
FinePix A605	Small Point & Shoot
FinePix A607 Zoom	Small Point & Shoot
FinePix A820	Small Point & Shoot
FinePix A900	Small Point & Shoot
FinePix A920	Small Point & Shoot
FinePix E500/510/550/900 Zoom	Small Point & Shoot
FinePix F10/11/30 Zoom	Small Point & Shoot
FinePix F40FD	Mini Point & Shoot or Small Hard Lens
FinePix F420/440/450/455/460/470 Zoom	Small Point & Shoot
FinePix F480	Mini Point & Shoot or Small Hard Lens
FinePix F610/710/810 Zoom	Small Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
FinePix IS-1	Sorry, no fit
FinePix S1/2/3 Pro	Sorry, no fit
FinePix S5 Pro	Sorry, no fit
FinePix S700	Large Point & Shoot
FinePix S20 Pro Zoom	Sorry, no fit
FinePix S3100/5100/5600/7000/9500	Sorry, no fit
FinePix S6000fd	SLR
FinePix S8000fd	SLR
FinePix S9100	SLR
FinePix V10	Small Point & Shoot
FinePix Z1/2 Zoom	Small Point & Shoot
FinePix Z5fd	Mini Point & Shoot or Small Hard Lens
FinePix Z10fd	Mini Point & Shoot or Small Hard Lens
FinePix Z40fd	Mini Point & Shoot or Small Hard Lens
FinePix Z50fd	Mini Point & Shoot or Small Hard Lens
Fuji Finepix 2650	Large Point & Shoot
HP	
Photosmart E317/327	Small Point & Shoot
Photosmart M22	Small Point & Shoot
Photosmart M417/517	Small Point & Shoot
Photosmart M525/527	Small Point & Shoot
Photosmart R717/727/817/818/927	Small Point & Shoot
Photosmart 945	Sorry, no fit
Kodak	
DC200/210	Large Point & Shoot
DC200/210 Plus	Large Point & Shoot
DC215/220/240/260/265/280/290	Large Point & Shoot
DC3400/3800	Small Point & Shoot
DC3200/4800/5000	Large Point & Shoot
DCS315/330/420/460/520/560/620/660/760	Sorry, no fit
DCS620/720x	Sorry, no fit
DX-3700	Sorry, no fit
Easyshare C300/310/315/330/360	Small Point & Shoot
Easyshare C340	Large Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
Easyshare C503/530/533/603/643/663	Small Point & Shoot
EasyShare C613	Small Point & Shoot
EasyShare C653	Small Point & Shoot
Easyshare C875	Small Point & Shoot
Easyshare CD33/40/43	Small Point & Shoot
Easyshare CW330	Small Point & Shoot
Easyshare CX4310	Small Point & Shoot
Easyshare CX6230/6300/6330/6445	Small Point & Shoot
Easyshare CX7220/7300/7310/7330	Small Point & Shoot
Easyshare CX7430/7525/7530	Small Point & Shoot
Easyshare DX3215/3500/3600/3700/3900	Small Point & Shoot
Easyshare DX4330/4530/7630	Small Point & Shoot
Easyshare DX6340/6440/7440	Small Point & Shoot
Easyshare DX6490/7590	Large Point & Shoot
Easyshare LS633/743/753/755	Small Point & Shoot
EasyShare M753	Mini Point & Shoot or Small Hard Lens
EasyShare M853	Mini Point & Shoot or Small Hard Lens
Easyshare P850	Large Point & Shoot or SLR
Easyshare P880	Sorry, no fit
EasyShare V1233	Small Point & Shoot
EasyShare V1003	Mini Point & Shoot or Small Hard Lens
Easyshare V530/550/603	Small Point & Shoot
Easyshare V570/610 Dual Lens	Small Point & Shoot
EasyShare V803	Mini Point & Shoot or Small Hard Lens
EasyShare V1253	Mini Point & Shoot or Small Hard Lens
Easyshare Z612/650	Large Point & Shoot
Easyshare Z712 IS	SLR
Easyshare Z700/730/740/760	Large Point & Shoot
EasyShare Z812	SLR
EasyShare Z885	Small Point & Shoot
Easyshare Z7590	Large Point & Shoot
EasyShare Z1275	Small Point & Shoot
Konica	
KD 100	Small Point & Shoot
KD 220Z	Small Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
KD 310Z	Small Point & Shoot
KD 400Z	Small Point & Shoot
KD 500Z/500G	Small Point & Shoot
KD 510Z	Small Point & Shoot
Revio C2	Small Point & Shoot
Minolta Maxxum 5D	SLR
Minolta A200	Sorry, no fit
Kyocera	
Finecam L3/L3v/L4/L4v/S3L/S3X/S4/S5/S5R	Small Point & Shoot
Finecam M410R	Large Point & Shoot
Lecia	
M7	
MP	Large Point & Shoot
R8/9	Large Point & Shoot
C-LUX 2	Mini Point & Shoot or Small Hard Lens
D-LUX 3	Large Point & Shoot
CM/CM Zoom	Sorry, no fit
V-Lux 1	SLR
Minolta	
Dimage 5	SLR
Dimage 7/7i/ 7hi	Sorry, no fit
Dimage A1 / A2	Sorry, no fit
Dimage E223	Sorry, no fit
Dimage E323	Small Point & Shoot
Dimage F200	Small Point & Shoot
Dimage F300	Small Point & Shoot
Dimage S414	Small Point & Shoot
Dimage xt / xi / x / x20 / x50 / x60	Small Point & Shoot
Dimage Z1, Z2/3/20	Small Point & Shoot
Dimage Z10	Sorry, no fit
Dynax 303	Large Point & Shoot
Dynax 3L	Sorry, no fit
Dynax 4	SLR

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon **Casio** **Contax** **Espon** **Fuji** **HP** **Kodak** **Konica**
Kyocera (Yashica) **Lecia** **Minolta** **Nikon** **Olympus** **Panasonic**
Pentax **Picoh** **Samsung** **Sanyo** **Sigma** **Sony**

Make/Model	Camera Case
Dynax 404	SLR
Dynax 5	Sorry, no fit
Dynax 7	SLR
Dynax 9	Sorry, no fit
Maxxum 3 QD / 4 QD / 5 QD	Sorry, no fit
Maxxum 500si	SLR
Maxxum 7	Sorry, no fit
Maxxum 7D/700si	SLR
Maxxum 8000i	Sorry, no fit
Maxxum 800si	Sorry, no fit
Maxxum 9	Sorry, no fit
Maxxum HTsi	Sorry, no fit
Maxxum QTsi	SLR
Maxxum STsi (QD)	SLR
Maxxum XTsi	SLR
RD3000	SLR
Riva 140mm	Sorry, no fit
Vectis S-1	Small Point & Shoot
Vectis S-100	SLR
X-370	SLR
	Large Point & Shoot
Nikon	
AF220/230/240/250	
Coolpix L1	Small Point & Shoot
Coolpix L11	Mini Point & Shoot or Small Hard Lens
Coolpix L14	Mini Point & Shoot or Small Hard Lens
Coolpix L15	Mini Point & Shoot or Small Hard Lens
Coolpix P1	Small Point & Shoot
Coolpix P50	Small Point & Shoot
Coolpix P5100	Small Point & Shoot
Coolpix 3100/3200/2100/2000	Small Point & Shoot
Coolpix 4.3 (zoom lens too large for Small Point & Shoot)	Large Point & Shoot
Coolpix 3700/4300/4600/4100/2500	Small Point & Shoot
Coolpix 5200	Small Point & Shoot
Coolpix 5400/SQ/4500/4800	Small Point & Shoot
Coolpix 775	Large Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Coolpix 7600	Small Point & Shoot
Coolpix 3500	Small Point & Shoot
Coolpix 5900/7900	Small Point & Shoot
Coolpix 5000	SLR
Coolpix 8700	Large Point & Shoot
Coolpix 5700/8800	Sorry, no fit
Coolpix 880/885/990/995	Sorry, no fit
Coolpix 775	Large Point & Shoot
Coolpix S200	Mini Point & Shoot or Small Hard Lens
Coolpix S51	Mini Point & Shoot or Small Hard Lens
Coolpix S50c	Mini Point & Shoot or Small Hard Lens
Coolpix S51c	Mini Point & Shoot or Small Hard Lens
Coolpix S510	Mini Point & Shoot or Small Hard Lens
Coolpix S700	Mini Point & Shoot or Small Hard Lens
D1X/D2X/D2XS	Sorry, no fit
D2H	Sorry, no fit
D40	SLR
D50	SLR
D70	SLR
D80	Sorry, no fit
D 100/200	Sorry, no fit
F100	SLR
F3HP	Sorry, no fit
F4s	Sorry, no fit
F5/F6	Sorry, no fit
F65/ 55/55D	Sorry, no fit
F80D	SLR
F90x	SLR
FM10	Sorry, no fit
FM2N	SLR
FM3A	Sorry, no fit
LiteTouch " 110/ 130/ 150	SLR
LiteTouch Zoom 70w/100w	Small Point & Shoot
N55	Small Point & Shoot
N60	SLR
N65	SLR

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
N70	SLR
N75	SLR
N80	SLR
N8008s	SLR
N90s	Large Point & Shoot
Nuvis Mini1/75i/125i	SLR
OneTouch Zoom 90/90s	Small Point & Shoot
Pronea 600i/6i	Small Point & Shoot
Pronea S	SLR
Zoom 3120AF	SLR
	Small Point & Shoot
Olympus	
700BF/800	
Accura 80	Small Point & Shoot
C - 1/ 21/ 100/ 220Z/ 720Z	Small Point & Shoot
C - 1Z/ 4/ 8/ 9/ 50/ 51/ 60/ 300	Small Point & Shoot
C - 200Z/350Z/860L/990Z	Small Point & Shoot
C - 700UZ/720UZ/730UZ	Small Point & Shoot
camedia c-60	Small Point & Shoot
C - 740/ 960/ 970	Large Point & Shoot
C - 765 Ultra Zoom	Large Point & Shoot
C - 7000	Large Point & Shoot
C- 150/350/500/505	Small Point & Shoot
C- 2000Z/2020Z/2040Z/3000	Small Point & Shoot
C- 3020Z/3030Z/3040Z/4040/990Z	Large Point & Shoot
C- 4000/5050/5060	Large Point & Shoot
C- 4040Zoom	Large Point & Shoot
C- 740/750/760/765/770/730UZ	Large Point & Shoot
C700/C2100UZ	Large Point & Shoot
C2500L	Sorry, no fit
C5050Z	Sorry, no fit
C-8080 Wide Zoom	Large Point & Shoot
Camedia C-40/50Zoom	Sorry, no fit
D- 560/390/510/550/580/630	Small Point & Shoot
D-500L/600L/620L	Small Point & Shoot
E-1/10/20	Sorry, no fit

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
E-100RS/	Sorry, no fit
E-400	Large Point & Shoot or SLR
IS-20 (QD)	Sorry, no fit
IS-30	Sorry, no fit
IS-5	Sorry, no fit
IS-50	Sorry, no fit
Evolt E-500	SLR
Evolt E-330	SLR
Evolt E-300/	Sorry, no fit
LT Zoom 105/120	SLR
MJU - 1/ II	Small Point & Shoot
MJU 300	Small Point & Shoot
MJU 400	Small Point & Shoot
MJU III Zoom 115/120	Small Point & Shoot
MJU Zoom 115/80/140	Small Point & Shoot
Newpic 60	Small Point & Shoot
FE-115	Small Point & Shoot
FE-210	Mini Point & Shoot or Small Hard Lens
FE-230	Mini Point & Shoot or Small Hard Lens
FE-280	Mini Point & Shoot or Small Hard Lens
FE-290	Mini Point & Shoot or Small Hard Lens
OM-2	Small Point & Shoot
OZ10	SLR
Stylus 35mm	Small Point & Shoot
Stylus 740	Mini Point & Shoot or Small Hard Lens
Stylus 750	Mini Point & Shoot or Small Hard Lens
Stylus 760	Mini Point & Shoot or Small Hard Lens
Stylus 780	Mini Point & Shoot or Small Hard Lens
Stylus 820	Mini Point & Shoot or Small Hard Lens
Stylus 830	Mini Point & Shoot or Small Hard Lens
Stylus 1200	Mini Point & Shoot or Small Hard Lens
SP-510 UZ	Large
SP-550 UZ	SLR
SP-560 UZ	SLR
Stylus Verve	Small Point & Shoot
Stylus Zoom 140/400/ 300	Small Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Superzoom 700BF / 800	Large Point & Shoot
Superzoom 80W/105/120	Small Point & Shoot
Zoom 2000	Small Point & Shoot
Zoom 310	Large Point & Shoot
	Small Point & Shoot
Panasonic	
DMC F1/F7	Small Point & Shoot
DMC FZ 1/FZ3 / FZ7 / FZ8	SLR
DMC FZ4S/FZ5S	Large Point & Shoot or SLR
DMC FZ 5/10/15/20	SLR
Lumix DMC-FZ18 / FZ28	SLR
DMC FZ50	SLR
DMC LZ1/LZ2/LZ2K	Sorry, no fit
DMC LZ6 / LZ7	SLR
DMC LC20	Small Point & Shoot
DMC LC40	Small Point & Shoot
DMC LC43/33/80	Large Point & Shoot
DMC LC5	Small Point & Shoot
DMC LS2	Small Point & Shoot
Lumix DMC-LS75	Small Point & Shoot
DMC LX1	Large Point & Shoot
Lumix DMC-LX2	Small Point & Shoot
DMC FX7/ FX9	Small Point & Shoot
Lumix DMC-FX10	Mini Point & Shoot or Small Hard Lens
Lumix DMC-FX12	Mini Point & Shoot or Small Hard Lens
Lumix DMC-FX30 / 33	Mini Point & Shoot or Small Hard Lens
Lumix DMC-FX55	Mini Point & Shoot or Small Hard Lens
Lumix DMC-FX100	Mini Point & Shoot or Small Hard Lens
DMC-FX01	Small Point & Shoot
DMC-TZ1 10x Zoom	Small Point & Shoot
DMC-TZ3	Large Point & Shoot
Pentax	
EI - 100	
EI - 200	Small Point & Shoot
EI-2000	Small Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
ESPIO 110Zoom/120/140/160	Sorry, no fit
ESPIO 115M Zoom	Large Point & Shoot
ESPIO 90MC/ 738G/838/928	Small Point & Shoot
A30	Mini Point & Shoot or Small Hard Lens
Optio M40	Mini Point & Shoot or Small Hard Lens
Optio WP	Large Point & Shoot
Optio W20/30	Small Point & Shoot
Optio E40	Mini Point & Shoot or Small Hard Lens
Optio S /S4/S6	Small Point & Shoot
Optio S/330/550/450/33L/330	Small Point & Shoot
Optio S5i /S5Z	Small Point & Shoot
Optio Z10	Mini Point & Shoot or Small Hard Lens
Lumix DMC-LS75	
115M	Small Point & Shoot
160/738G/838/928	Small Point & Shoot
K10D	SLR
Istd	SLR
MZ-S (QD)	SLR
645N	SLR
Pro90 IS	Sorry, no fit
Pz-1p	Sorry, no fit
ZX 30	Sorry, no fit
ZX 5n	Sorry, no fit
ZX 60	SLR
ZX L	SLR
ZX M	SLR
Ricoh	
Caplio R4	No Fit
Ricoh Caplio R6	Small Point & Shoot
Caplio G3 /G4	Small Point & Shoot
Caplio RR 30/230	Small Point & Shoot
Caplio RR1 /RDC-7	Small Point & Shoot
RDC-5300	Small Point & Shoot
GR - 21	Large Point & Shoot

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Samsung	
Digimax 101	Small Point & Shoot
Digimax 201/301	Small Point & Shoot
Digimax 230/ 350	Small Point & Shoot
Digimax 240	Small Point & Shoot
Digimax 50 Duo/130/200/V4	Small Point & Shoot
Digimax 370	Large Point & Shoot
Digimax 330	Large Point & Shoot
Digimax S800	Small Point & Shoot
L700	Mini Point & Shoot or Small Hard Lens
L730	Mini Point & Shoot or Small Hard Lens
L830	Mini Point & Shoot or Small Hard Lens
L73	Mini Point & Shoot or Small Hard Lens
L74	Small Point & Shoot
L77	Small Point & Shoot
NV7 OPS	
NV10	Small Point & Shoot
NV11	Small Point & Shoot
NV20	Small Point & Shoot
SDC - 200Z Nexca	Large Point & Shoot
i85	Mini Point & Shoot or Small Hard Lens
S630 / 630	Mini Point & Shoot or Small Hard Lens
S85	Small Point & Shoot
S1050	Small Point & Shoot
SR4000	SLR
S73	Mini Point & Shoot or Small Hard Lens
S730	Mini Point & Shoot or Small Hard Lens
Sanyo	
DSC-J1	Small Point & Shoot
Sigma	
SA7N	SLR
SA9	Sorry, no fit
SD9	SLR
SD9/10	Sorry, no fit

AQUAPAC Fit Guide - Cameras

These fit guides are compiled using the dimensions of each model. They do not take into consideration the workings of each model

Canon Casio Contax Espon Fuji HP Kodak Konica
Kyocera (Yashica) Lecia Minolta Nikon Olympus Panasonic
Pentax Picoh Samsung Sanyo Sigma Sony

Make/Model	Camera Case
Sony	
DSC-F77/77X/88	Small Point & Shoot
DSC-F707/717/828	Sorry, no fit
Cyber-shot DSC-G1	Mini Point & Shoot or Small Hard Lens
DSC-H1/2/5/9	Sorry, no fit
Cyber-shot DSC-H3	
Cyber-shot DSC-H7	
DSC-L1/N1	Small Point & Shoot
Cybershot DSC-N2	Small Point & Shoot
DSC-P1-10/12/32/41/43/52/71/72/73/92/93/93A	Small Point & Shoot
DSC-P100/150/200	Small Point & Shoot
DSC-R1	Sorry, no fit
DSC-S40/60/80/90	Small Point & Shoot
DSC - S75	Large Point & Shoot
DSC-S85	Large Point & Shoot
DSC-S500	Small Point & Shoot
DSC-S700	
Cyber-shot DSC-H3	
DSC-T1/3/5/5N/7/9/30/33	Small Point & Shoot
Cyber-shot DSC-T20	Mini Point & Shoot or Small Hard Lens
Cyber-shot DSC-T70	Mini Point & Shoot or Small Hard Lens
Cyber-shot DSC-T100	Mini Point & Shoot or Small Hard Lens
Cyber-shot DSC-T200	Mini Point & Shoot or Small Hard Lens
DSC-U20/30/40	Small Point & Shoot
DSC-V1	Small Point & Shoot
DSC-V3	Large Point & Shoot
DSC-W1/5/7/30/50/70/100	Small Point & Shoot
Cybershot DSC-W55	Mini Point & Shoot or Small Hard Lens
Cyber-shot DSC-W80	Mini Point & Shoot or Small Hard Lens
Cybershot DSC-W90	Mini Point & Shoot or Small Hard Lens
Cyber-shot DSC-W200	Mini Point & Shoot or Small Hard Lens
DSLR-A100	SLR